## **Assembly Instructions**Daintree 3 Support - 1.8 m FS

1800 REPLAS

## Parts List

Seat Slat (x7)

Daintree Support (x3)

Bugle Screw 14g x 75 mm (x21)




## **Instructions**

Step 1 Using a 5 mm hexagonal drive, partly screw each slat onto the supports. Fixing the bottom slats first is recommended.

Step 2 Ensure that the supports are vertical and slats are square with the supports.

Step 3 Finally tighten all screws, taking care not to over tighten as this could strip the screws.

## Diagram



All dimensions are in millimetres (mm) unless specified.