

Parts List

Metal Armrest (x2)

14g x 35 mm Hex Screw (x12)



Kimberley



Kakadu



Daintree

Instructions

Step 1 Once assembled, place the armrests on the seat as per above pictures.

Step 2 Pre-drill holes using a 4 or 4.5 mm drill bit.

Step 3 Attach the armrests with the 35 mm Hex screws supplied.