

Parts List

Seat Slat (x6)
Kimberley Support (x3)
Bugle Screw 14g x 75mm (x18)



Instructions

- Step 1** Using a 5mm hexagonal drive, partly screw each slat onto the supports. Fixing the bottom slats first is recommended.
- Step 2** Ensure that the supports are vertical and slats are square with the supports.
- Step 3** Finally tighten all screws, taking care not to over tighten as this could strip the screws.

Diagram

