

### Parts List

Seat Slat (x6)
Kimberley Support In Ground (x5)
Bugle Screw 14g x 75mm (x30)

### Instructions

**Step 1** Using 5mm hexagonal drive, partly screw the bottom slats into the supports and then the rear slats. Once all slats are in place ensure the end of the slats are square, then tighten all screws taking care not to over tighten as this could strip the screws.

**Step 2** Ensure that the seat slats are at right angles to the supports and supports are vertical.

**Step 3** Finally tighten all screws taking care not to over tighten and this could strip the screws.

**Step 4** Drill or dig holes approximately 500mm deep (depending on the height you want the seat above the ground) at 802mm centres.

**Step 5** Place the supports of the assembled seat into the holes. Position the seat and ensure that the seat is well braced to prevent movement and sagging. At this stage it is important to use a spirit level to check that the seat is horizontal and the supports are vertical.

**Step 6** Once satisfied that the seat is positioned correctly, fill with concrete, making sure it is packed firmly around the supports. Once the concrete has set, remove the bracing.

### Diagram

