

### Parts List

Seat Slat (x13)

Kimberley In Ground Support (x3)

Bugle Screw (x39)

### Instructions

**Step 1** Using a 5mm hexagonal drive, partly screw each slat onto the supports. Fixing the bottom slats first is recommended.

**Step 2** Ensure that the supports are vertical and slats are square with the supports.

**Step 3** Finally tighten all screws, taking care not to over tighten as this could strip the screws.

**Step 4** Drill or dig holes approximately 500mm deep (depending on the height you want the seat above the ground) at 705mm centres.

**Step 5** Place the supports of the assembled seat into the holes. Position the seat and ensure that the seat is well braced to prevent movement and sagging. At this stage it is important to use a spirit level to check that the seat is horizontal and the supports are vertical.

**Step 6** Once satisfied that the seat is positioned correctly, fill with concrete, making sure it is packed firmly around the supports. Once the concrete has set, remove the bracing.

### Diagram

